





- 1. Waterproofing the entire floor when the floor is tiled is recommended.
- 2. The entire floor should be waterproofed if the substrate is timber, particleboard or plywood (AS 3740-2010).
- 3. The edge of the waterproofing membrane should be terminated at a waterstop.

Required extent of waterproofing (E3/AS1).